




1. Select my computer, enter manage, as below picture.



2. Select Device manager -> Universal Serial Bus controllers ->USB 3.0 Hub, enter Properties, as below picture



3. Select Details -> Hardware Ids, as below picture



4. Check the FW version, as below picture: VL812, FW:8581

