



Lighting

Welcome Guide

Starlit String Light with Remote Control

Safety Instructions


Read and follow all the safety instructions:

- This product is not rated water resistant and should be protected from water.
- This is a seasonal-use product not intended for permanent installation or use.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Unplug the product when leaving the house, retiring for the night, or otherwise leaving it unattended.
- This is an electrical product—not a toy! To avoid risk of fire, burns, electric shock, and other injuries and property damage, it should not be played with or placed where small children or pets can reach it.
- Do not cover the product with cloth, paper or any other material not part of the product, when in use.
- To reduce the risk of fire and electric shock, do not attempt to replace the LEDs or modify the cable.
- To reduce the risk of fire and electric shock, use only the TS-4.5V1A power supply that was provided with this product.
- If the product is placed on a tree, the tree should be well-secured and stable.
- Do not operate this product in the presence of corrosive gases, or near electric heaters, open fires or other heat sources.
- If any part of the product is damaged, the product should be disposed of.
- Do not connect this product electrically to other string lights.
- This product must be disposed of safely according to local environmental regulations.


▶1

Installation

- 1 Unwind the string light and put it where you want to use it.
- 2 Connect one end of the LED controller to the string light and the other end to the power adapter.



- 3 Plug the adapter into an outlet.









Do not stretch or pull the string light, as this could damage it and pose a safety risk.

▶2

For FAQs and more information, please visit:

www.eufylife.com

Controls

	Press to turn string light on / off.
	Press to return to steady-on mode.
	Press to adjust the brightness.
	Press to select the brightness level.
	Press to switch between 10 light effect modes.
	Press to adjust the flashing speed.

Specifications

Power Adapter Model	TS-4.5V1A
Adapter Input	AC 120 V / 60 Hz
Adapter Output	DC 4.5 V \equiv 1 A
IP Rating	IP20
String Light Length	10 m / 33 ft



This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio / TV technician for help.

Customer Service

-  12-month limited warranty
-  Lifetime technical support
-  support@eufylife.com
-  1-800-988-7973 (US) | Mon-Fri 9:00-17:00 (PST)
-  @EufyOfficial
-  @EufyOfficial
-  @EufyOfficial
-  @EufyOfficial

© Anker Technology Co. Limited. All rights reserved. Eufy and the Eufy logo are trademarks of Anker Technology Co. Limited, registered in the United States and other countries. All other trademarks are the property of their respective owners.